
Meridian 1

Option 11C

ISDN BRI Administration and Maintenance

Document Number: 553-3011-311
Document Release: Standard 6.00
Date: October 1997

© 1993, 1997
All rights reserved

Printed in Canada

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

Meridian 1 is a trademark of Northern Telecom.

Revision history

October 1997

Issue 6.00 released as Standard for Generic X11 Release 23.

July 1996

Issue 5.00 released as Standard for Generic X11 Release 22.

December 1995

Issue 4.00 released as Standard for Generic X11 Release 21B.

July 1995

Issue 3.00 released as Standard for Generic X11 Release 21A.

December 1994

Issue 2.00 released as Standard for Generic X11 Release 20.

October 1993

Release 1.00, Standard

Contents

About this guide	v
Chapter 1 — ISDN Basic Rate Interface	1
Introduction	1
ISDN Overview	1
ISDN Basic Rate Interface	2
ISDN BRI protocol	5
ISDN BRI line access	7
ISDN BRI Packet Data Transmission	12
ISDN BRI trunk access	14
ISDN BRI Local Exchange/DID connectivity	16
1TR6 local exchange connectivity	17
Numeris VN2 local exchange connectivity	18
Japan D70 (INS NET-64) local exchange connectivity (non-Asia Pacific protocol)	19
EuroISDN connectivity	20
Asia-Pacific connectivity	21
ISDN BRI trunk connectivity	23
ISDN BRI TIE trunk connectivity	23
QSIG ISDN BRI trunk connectivity	26
Chapter 2 — Feature descriptions	29
Introduction	29
ISDN BRI specific features	30
Calling Line Identification Presentation and Restriction	31
National ISDN-1 Conference	32

ISDN BRI circuit-switched data calls	36
ISDN BRI Special Call Forward Busy	40
ISDN BRI Special Hunting	40
ISDN BRI ETSI Call Forwarding Unconditional	41
ISDN BRI ETSI Conference	46
ISDN BRI National ISDN-1 Call Forward All Calls	49
ISDN Basic Rate Interface Connected Line Presentation/Restriction	54
NI-1 BRI Compliance Enhancements	60
Set-based ISDN BRI features on Meridian 1 ISDN BRI terminals	63
Generic X11 features	64
ISDN BRI Lines	64
Features supported by ISDN BRI as a Line	86
Features partially supported by ISDN BRI as a line	91
ISDN BRI Trunk Access features	99
Generic X11 International features — lines and trunks	103
Generic X11 International features interaction	103
Generic X11 International features partially supported	114

Chapter 3 — Feature packaging and prerequisites 129

Introduction	129
Feature packages and prerequisites	129
ISDN Basic Rate Interface (BRI) packages	130
ISDN BRI Trunk applications (BRIT) package	131
ISDN BRI Line applications (BRIL) package	131
EuroISDN (EURO) package	131
QSIG (QSIG) package	131

Chapter 4 — Network clocking 133

Introduction	133
The Need for Synchronization	133
Synchronization Methods	134
Hierarchical synchronization	134
Stratum Levels	136
Guidelines	136
Option 11 clock controllers	144

Tracking mode	144
Free-run (non-tracking)	145
Chapter 5—ISDN BRI line and packet data implementation	147
Introduction	147
ISDN BRI line configuration guidelines	148
DSL configuration	149
SILC DSL configuration	149
Line powering options	150
UILC DSL configuration	161
ISDN BRI terminals	165
Terminal addressing and service profile assignment	166
Packet Data Configuration	173
Hardware Requirements	175
NTBK22 Multi-Purpose ISDN Signaling Processor (MISP) card ..	176
NT6D70AA/NT6D70BA S/T Interface Line card (SILC)	177
NT6D71 U Interface Line Card (UILC)	179
NTAK09/NTAK10/NTBK50 PRI card	181
Data Packet Network (DPN-100)	182
Network Termination 1 (NT1)	182
ISDN BRI terminals	183
Installing ISDN BRI Hardware	184
Installation procedures	184
Selecting the card slots	185
Installing the MISPs	188
Installing SILCs and UILCs	189
Installing PRI hardware	192
Connecting ISDN BRI terminals	193
Programming procedures for line application and packet data transmission	211
Chapter 6 — ISDN BRI trunk implementation	231
Introduction	231
ISDN BRI trunk access	232

ISDN BRI local exchange/CO/DIDconnectivity	233
ISDN BRI MCDN Tie trunk connectivity	241
ISDN BRI QSIG connectivity	245
Hardware Requirements	247
NTBK22 Multi-Purpose ISDN Signaling Processor (MISP) card	248
NT6D70AA/NT6D70BA S/T Interface Line card (SILC)	249
NT6D71 U Interface Line Card (UILC)	250
Clock controller	250
Network Termination 1 (NT1)	250
Cables	251
Installing BRI hardware	252
Installation procedures	252
Selecting the card slots	252
Installing the clock controller on the MISP	256
Installing the MISPs	256
Installing SILCs and UILCs	258
Connecting Option 11 cables to the cross-connect terminal	260
Cross-connecting DSLs at the cross-connect terminal	264
ISDN BRI trunk software programming	270
Chapter 7 — Acceptance testing	293
Verifying ISDN BRI operation	293
Setting up ISDN BRI test terminals and trunks	293
Testing ISDN BRI functions	297
Voice calls	297
Circuit-switched data calls	305
Packet data transmission	306
Testing ISDN BRI trunk connectivity	308
Removing the test setup	308
Chapter 8 — Service changes and maintenance	309
Introduction	309
ISDN BRI maintenance commands	309
Maintenance commands	309
MISP and SILC/UILC message monitoring commands	314

Changing, removing and printing an LAPD protocol group	315
Changing, removing and printing an MISP	317
Changing, removing and printing an SILC or UILC	319
Changing or Removing a DSL	320
Changing, removing and printing a TSP	331
Isolating and correcting faults	337
Newly installed ISDN BRI equipment	337
Previously operating ISDN BRI equipment	337
Isolating faults	337
MISP fault isolation and correction	340
SILC fault isolation or UILC fault isolation and correction	352
Replacing ISDN BRI cards	359
Removing and replacing the MISP	359
Removing and replacing the SILC or UILC	360
Verifying operation	361
Packing and shipping defective cards	361
Testing and troubleshooting ISDN BRI terminals	362
Verifying a new M5317T terminal installation	362
Troubleshooting the M5317T	362
Verifying a new M5209T terminal installation	364
Troubleshooting the M5209T	367
ISDN BRI messages	369
Basic Rate Interface messages (BRIxxx)	370
Basic Rate Interface Trunk messages (BRIT)	383
Background signaling diagnostic messages (BSDxxx)	384
Software error monitor messages (BUGxxxx)	387
Equipment data dump messages (EDDxxx)	389
Error monitor messages (ERRxxxx)	389
Network link messages (LNKxxx)	390
Network and peripheral replacement messages (NPRxxx)	391
Network and signal diagnostic messages (NWSxxx)	393
Service change messages (SCHxxxx)	394
System loader messages (SYSxxxx)	406
Chapter 9 — ISDN BRI traffic reports	409
Introduction	409

Traffic report types	409
Understanding Option 11 traffic reports	410
Network traffic report	411
MISP/DSL traffic report	414
MISP D-channel management messages report	415
MISP messages report	416
MISP messages for BRIT application	417
Generating traffic reports	418
Appendix A — 2Mb PRI implementation	421
Overview	421
Hardware requirements	422
Circuit cards	422
Cables	422
Hardware description	423
2.0 Mb PRI cards	423
NTAK20 Clock Controller (CC) daughterboard	424
NTAK93 D-Channel Handler Interface (DCHI) daughterboard ..	424
NTBK51 Downloadable D-Channel daughterboard	425
Installing PRI hardware: NTAK79 PRI card	425
Inspecting the NTAK79 circuit card	425
Setting the switches on the NTAK79	426
Inserting the NTAK79 into the main cabinet	428
Connecting the cables	428
Installing PRI hardware: NTBK50 PRI card	430
Inspecting the NTBK50 circuit card	430
Setting the switches on the NTBK50	431
Mounting the daughterboards on the NTBK50	433
Inserting the NTBK50 into the main cabinet	435
Connecting the cables	435
PRI software programming	437
Limitations	437
Procedure summary	438
PRI software programming: Option 11 to Central Office (ISA)	449
Introduction	449

Purpose	449
Limitations	450
Dependencies	451
ISA Prompt Assignments	451
Configuring Option 11 to Central Office (ISA)	453
Applicability	453
Limitations	453
Procedure summary	454
List of terms and abbreviations	467